# M4 G2 CABLE DRAWINGS
## STEP: 1

58) Attach part no. 31 to part no 2 using one 1/2" x 3 1/4" hex bolt.

59) Connect part nos. 30 and 31 using two fa-2 cable assemblies. (The nuts on the ends of cable assemblies should thread down onto the flat sides of the chrome rods in part nos. 30 and 31)

*Note: The threaded end of the cable assemblies should pass through the nut after being tightened, otherwise, they may slip out.*

fig. 15

| Part Number | Description | Qty |
|---|---|---|
| FA-2 | Foot Assist Cable | 2 |